# A/V System User Guide

This conference room is equipped with a plasma screen with a stationary furniture layout (fixed table).

## **Table of Contents**

Technical Assistance Information	2
Presentation Setup	3
Internet Connection	
Phone Connection.	4
Projection Troubleshooting Tips	5

PLEASE DO NOT REMOVE FURNITURE OR EQUIPMENT FROM THIS ROOM WITHOUT FIRST CONTACTING THE RIIT GROUP

IF YOUR EVENT INVOLVES FOOD OR BEVERAGE, PLEASE MAKE SURE THE CONFERENCE ROOM IS LEFT IN GOOD CONDITION FOR THE NEXT EVENT

(CLEANING SUPPLIES PROVIDED INSIDE CREDENZA CABINET)

## **Technical Assistance Information**

Conference rooms equipped with data projectors should have instructions placed inside the Credenza cabinet (see labeled door, **Figure 1-1**). For additional support, you may want to schedule technical assistance through Footprints (by contacting your departmental staff assistant to issue a work order) or by emailing <a href="mili@smeal.psu.edu">riit@smeal.psu.edu</a>. If you are experiencing problems with your presentation (missing/broken cables, etc.), please call for assistance at **(814) 865-0366.** 

The phone is located inside the labeled Credenza cabinet

Conference rooms equipped with a plasma TV should have instructions placed behind the sliding whiteboard, near the TV. If you need additional support, you may want to schedule technical assistance through Footprints (contacting your departmental staff assistant to issue a work order) or by emailing <a href="mailto:riit@smeal.psu.edu">riit@smeal.psu.edu</a>.

**Step 1 -** Based on your presentation requirements, connect the provided VGA, audio, and network cables from the connection/power flip box on the table to your laptop.



**Step 2 -** Turn on the plasma TV manually (located behind the sliding whiteboard). If the correct source for the plasma is not already chosen, press the **Input** button (located lower left) until it is on "**PC**".



**Step 3** – In the case of laptop presentation, you need to send the signal from your laptop to the projector by holding the function (Fn) key and pressing the proper F# key, depending on your laptop model. The following list may help:

Manufacturer	Key
Acer	Fn + F5
Dell	Fn + F8
НР	Fn + F5
IBM ThinkPad	Fn + F7
Sony	Fn + F7
Toshiba	Fn + F5



#### **INTERNET CONNECTION**

If an internet connection is required, there are two options:

- 1. Wired LAN connection
- 2. Wireless connection

Whichever connection is used, make sure the other is disabled.

- Wired LAN Connection
- Make sure Ethernet cable from the computer is connected into the port labeled "Mobility"
- Open Internet Explorer, select the PSU "<u>Port Login</u>" Site (https://clc.its.psu.edu/PortLogin.aspx)
- Log in using your PSU username/password
- Make sure to logout using PSU "<u>Port Logout</u>" Site (https://clc.its.psu.edu/PortLogout.aspx)
- Wireless Connection
- Open your Wireless Network Connection, connect to "pennstate"
- Open the VPN Client from the desktop
- Double-click "ITS Wireless at UP"
- Log in using your PSU username/password

#### PHONE CONNECTION

- Polycom conference-call machine available through Footprints or contact the RIIT Group via email: riit@smeal.psu.edu
- The RIIT Group A/V team will setup your phone connection for you based on your request
- This room's phone number is: (814) 863-5748

#### **Long-Distance Calls**

- Lift handset and listen for dial tone
- Enter the access code: 175 and wait for the special tone
- Enter your authorization code and immediately follow with the # sign
- Wait for dial tone
- Enter 8 (to dial outside of University Park)
- Enter all digits you would normally use when placing a call
- NOTE: Any calls placed using an authorization code will be billed against the budget associated with that code

http://tns.its.psu.edu/services/VOICE/authcode.html#sw

### PROJECTION TROUBLESHOOTING TIPS

PC (laptop) image does not appear on the plasma TV:

- After pressing the correct projection function, make sure you select the option that will show the presentation on plasma TV **AND** laptop at the resolution **1024** x **768**.
- If image still doesn't project, cycle through available plasma inputs to find correct source.
- In case that the image still doesn't project, check the VGA cable connection and connector for broken pins. If VGA cable is broken, or still cannot get image to project, please call the **RIIT Group** for immediate assistance at **865-0366**.